





Netvex Alot APP






- Data Trend Analysis
- Push Messages In Time
- Real Time Data Update
- Join The Network Quickly
- Display NB-IoT and LoRaWAN
 Device Data Simultaneously






How to Add LoRaWAN Gateways in the Netvox AloT APP




After logging in successfully, you will see the interface as shown above.
Click the button to add a device.




Select the project to which you want to add the gateway.







On the "Device Type" page, select "LoRaWAN Gateway".



On the "Add LoRaWAN Gateway" page, enter the Gateway ID, then click the "Start" button.






After the gateway is successfully added, a prompt will appear showing the gateway details as shown in the picture.



6 Click "Added Gateways" to view all gateways that have been added in the APP.

How to Add LoRaWAN Devices in the Netvox AloT APP




1 After logging in successfully, you will see the interface as shown above.

Click the button to add a device.




Select the project to which you want to add the devices.







"LoRaWAN Device".



On the "Add Smart Devices" page, enter the device IEEE address, then click the "Start" button.





Once the device is added successfully, a confirmation message will appear as shown.