

Wireless Activity Timer

Wireless Activity Timer

R313FC

User Manual

Copyright©Netvox Technology Co., Ltd.

This document contains proprietary technical information which is the property of NETVOX Technology. It shall be maintained in strict confidence and shall not be disclosed to other parties, in whole or in part, without written permission of NETVOX Technology. The specifications are subject to change without prior notice.

Table of Content

1. Introduction	2
2. Appearance	3
3. Main Features	3
4. Set up Instruction	4
5. Data Report	5
6. Installation.....	9
7. Relative Devices.....	10
8. Important Maintenance Instruction.....	10

1. Introduction

R313FC is a vibration alarm device for Netvox ClassA type device based on LoRaWAN open protocol. It can detect movement or vibration duration of the device and is compatible with LoRaWAN protocol.


LoRa Wireless Technology:

LoRa is a wireless communication technology dedicated to long distance and low power consumption. Compared with other communication methods, LoRa spread spectrum modulation method greatly increases to expand the communication distance. Widely used in long-distance, low-data wireless communications. For example, automatic meter reading, building automation equipment, wireless security systems, industrial monitoring. Main features include small size, low power consumption, transmission distance, anti-interference ability and so on.

LoRaWAN:

LoRaWAN uses LoRa technology to define end-to-end standard specifications to ensure interoperability between devices and gateways from different manufacturers.

2. Appearance



3. Main Features

- Compatible with LoRaWAN
- 2 section 3V CR2450 button battery powered
- Activity Timer
- Compatible with LoRaWAN™ Class A
- Frequency hopping spread spectrum technology
- Configuration parameters can be configured through third-party software platforms, data can be read and alarms can be set via SMS text and email (optional)
- Available third-party platform: Actility / ThingPark, TTN, MyDevices/Cayenne
- Low power consumption and long battery life

4. Set up Instruction

On/Off

Power on	Insert two sections of 3V CR2450 button batteries and close the battery cover
Turn on	Press any function key and the green and red indicator flash once.
Turn off (Restore to factory setting)	Press and hold the function key for 5 seconds and the green indicator flashes 20 times.
Power off	Remove Batteries.
Note:	<ol style="list-style-type: none"> 1. Remove and insert the battery; the device memorizes previous on/off state by default. 2. On/off interval is suggested to be about 10 seconds to avoid the interference of capacitor inductance and other energy storage components. 3. Press any function key and insert batteries at the same time; it will enter engineer testing mode.

Network Joining

Never joined the network	<p>Turn on the device to search the network to join.</p> <p>The green indicator stays on for 5 seconds: success</p> <p>The green indicator remains off: fail</p>
Had joined the network	<p>Turn on the device to search the previous network to join.</p> <p>The green indicator stays on for 5 seconds: success</p> <p>The green indicator remains off: fail</p>
Fail to join the network (when the device is on)	Suggest to check the device verification information on the gateway or consult your platform server provider.

Function Key

Press and hold for 5 seconds	<p>Restore to factory setting / Turn off</p> <p>The green indicator flashes 20 times: success</p> <p>The green indicator remains off: fail</p>
Press once	<p>The device is in the network: the green indicator flashes once and sends a report</p> <p>The device is not in the network: the green indicator remains off</p>

Sleeping Mode

The device is on and in the network	<p>Sleeping period: Min Interval.</p> <p>When the reportchange exceeds setting value or the state changes: send a data report according to Min Interval.</p>
-------------------------------------	--

Low Voltage Warning

Low Voltage	2.4V
-------------	------

5. Data Report

The device will immediately send a version packet report and the attribute report data

The device sends data in the default configuration before any configuration is done.

Default setting:

MaxTime: Max Interval = 60 min = 3600s

MinTime: Min Interval = 60 min = 3600s

Battery Voltage Change = 0x01 (0.1V)

Threshold = 0x0003 (Threshold range: 0x0003-0x00FF; 0x0003 is the most sensitive.)

Deactivetime = 0x05 (Deactive time range: 0x01-0xFF)

Threshold:

$Threshold = Critical\ value \div 9.8 \div 0.0625$

*The gravitational acceleration at standard atmospheric pressure is $9.8\ m/s^2$

*The scale factor of the threshold is 62.5 mg

R313FC vibration alarm:

The device detects sudden movement or vibration, and the quiescent state changes. The device waits for a certain period of time (DeactiveTime) to enter the quiescent state and calculate the duration, sends a report of duration of vibrations, and restarts the calculation for the next detection. If the vibration continues to occur within (DeactiveTime), the duration will be continuously calculated till it enters the quiescent state.

Note:

The device report interval will be programmed based on the default firmware which may vary.

The interval between two reports must be the minimum time.

Please refer Netvox *LoRaWAN Application Command document* and *Netvox Lora Command Resolver*

<http://www.netvox.com.cn:8888/cmddoc> to resolve uplink data.

Data report configuration and sending period are as following:

Min Interval (Unit:second)	Max Interval (Unit:second)	Reportable Change	Current Change \geq Reportable Change	Current Change $<$ Reportable Change
Any number between 1~65535	Any number between 1~65535	Can not be 0.	Report per Min Interval	Report per Max Interval

Example of data configuration:

FPort: 0x07

Bytes	1	1	Var(Fix =9 Bytes)
	CmdID	DeviceType	NetvoxPayLoadData

CmdID– 1 byte

DeviceType– 1 byte – Device Type of Device

NetvoxPayLoadData– var bytes (Max=9bytes)


Description	Device	Cmd ID	DeviceType	NetvoxPayLoadData				
Config ReportReq	R313FC	0x01	0x51	MinTime (2bytes Unit:s)	MaxTime (2bytes Unit:s)	BatteryChange (1byte Unit:0.1v)	Reserved (4Bytes,Fixed 0x00)	
Config ReportRsp		0x81		Status (0x00_success)		Reserved (8Bytes,Fixed 0x00)		
ReadConfig ReportReq		0x02		Reserved (9Bytes,Fixed 0x00)				
ReadConfig ReportRsp		0x82		MinTime (2bytes Unit:s)	MaxTime (2bytes Unit:s)	BatteryChange (1byte Unit:0.1v)	Reserved (4Bytes,Fixed 0x00)	
SetR313F TypeReq		0x03		R313FType (1Byte) 0x01_R313FA, 0x02_R313FB, 0x03_R313FC		Reserved (8Bytes,Fixed 0x00)		
SetR313F TypeRsp		0x83		Status (0x00_success)		Reserved (8Bytes,Fixed 0x00)		
GetR313F TypeReq		0x04		Reserved (9Bytes,Fixed 0x00)				
GetR313F TypeRsp		0x84		R313FType (1Byte) 0x01_R313FA, 0x02_R313FB, 0x03_R313FC		Reserved (8Bytes,Fixed 0x00)		
SetActive ThresholdReq		0x05		Threshold (2Bytes)	Deactivetime (1Byte,Unit:1s)		Reserved (6Bytes,Fixed 0x00)	
SetActive ThresholdRsp		0x85		Status (0x00_success)		Reserved (8Bytes,Fixed 0x00)		
GetActive ThresholdReq		0x06		Reserved (9Bytes,Fixed 0x00)				
GetActive ThresholdRsp		0x86		Threshold (2Bytes)	Deactivetime (1Byte,Unit:1s)		Reserved (6Bytes,Fixed 0x00)	

(1) Configure device parameters MinTime = 1min, MaxTime = 1min, BatteryChange = 0.1v


Downlink: 0151003C003C0100000000

Note:
 MaxTime=MinTime. Data will only be report according to MaxTime (MinTime) duration regardless BatteryVoltageChange value.

Example#2 based on MinTime = 15 Minutes, MaxTime= 1 Hour, Reportable Change i.e. BatteryVoltageChange= 0.1V.



Example#3 based on MinTime = 15 Minutes, MaxTime= 1 Hour, Reportable Change i.e. BatteryVoltageChange= 0.1V.



- Notes:
- 1) The device only wakes up and performs data sampling according to MinTime Interval. When it is sleeping, it does not collect data.
 - 2) The data collected is compared with the last data reported. If the data change value is greater than the ReportableChange value, the device reports according to MinTime interval. If the data variation is not greater than the last data reported, the device reports according to MaxTime interval.
 - 3) We do not recommend to set the MinTime Interval value too low. If the MinTime Interval is too low, the device wakes up frequently and the battery will be drained soon.
 - 4) Whenever the device sends a report, no matter resulting from data variation, button pushed or MaxTime interval, another cycle of MinTime / MaxTime calculation is started.

6. Installation

1. Remove the 3M adhesive on the back of the Activity Timer and attach the body to the surface of a smooth object (please do not stick it to a rough surface to prevent the device from falling off after a long time use).

Note:

- Wipe the surface clean before installation to avoid dust on the surface to affect the adhesion of the device.
- Do not install the device in a metal shielded box or other electrical equipment around it to avoid affecting the wireless transmission of the device.



Activity Timer (R313FC) is suitable for the following scenarios:

- Industrial Equipment
- Industrial Instrument
- Medical Instruments

When it necessary to detect the motor running time.




2. When the device detects a sudden movement or vibration of the object (or electrical machinery).

Wait for a certain period of time (DeactiveTime- default 5 seconds , can be modified) to enter the quiescent state and it sends a report of duration of vibrations, and restarts the calculation for the next detection, the timer data will clear.

Note:

- If the vibration continues to occur during this process (quiescent state), the timer continue calculation until the device enter the quiescent state.

7. Relative Devices

Model	Function	Appearance
R718MBA	Send an alarm when detecting vibration or movement	
R718MBB	Count the number of vibration or movement	
R718MBC	Count the time interval of vibration or movement	

8. Important Maintenance Instruction

Kindly pay attention to the following in order to achieve the best maintenance of the product:

- Keep the device dry. Rain, moisture, or any liquid, might contain minerals and thus corrode electronic circuits. If the device gets wet, please dry it completely.
- Do not use or store the device in dusty or dirty environment. It might damage its detachable parts and electronic components.
- Do not store the device under excessive heat condition. High temperature can shorten the life of electronic devices, destroy batteries, and deform or melt some plastic parts.
- Do not store the device in places that are too cold. Otherwise, when the temperature rises to normal temperature, moisture will form inside, which will destroy the board.
- Do not throw, knock or shake the device. Rough handling of equipment can destroy internal circuit boards and delicate structures.
- Do not clean the device with strong chemicals, detergents or strong detergents.
- Do not apply the device with paint. Smudges might block in the device and affect the operation.
- Do not throw the battery into the fire, or the battery will explode. Damaged batteries may also explode.

All of the above applies to your device, battery and accessories. If any device is not working properly, please take it to the nearest authorized service facility for repair.